

MEISSEN® COSMOPOLITAN



CONTENT



4	MEISSEN® COSMOPOLITAN	24	ROYAL PALACE BLACK
10	THE BUILDING BLOCKS	28	ROYAL PALACE TURQUOISE
16	THE DÉCOR WORLDS	32	ROYAL PALACE WHITE
118	ACCESSORIES	36	ROYAL PALACE RED
136	CRYSTAL	40	WHITE / MESH WHITE
142	MEISSEN® HOME	56	PLATINUM / MESH PLATINUM
		70	GOLD / MESH GOLD
		86	BLUE ORCHID PLATINUM
		94	BLUE ORCHID MESH WHITE
		100	BLACK MING DRAGON PLATINUM
		114	MIAMI STYLE TURQUOISE SEA
		116	MIAMI STYLE RED SUNSET

C

COSMOPOLITAN

A MUST FOR ALL INDIVIDUALISTS




MEISSEN® COSMOPOLITAN speaks a contemporary, architectonically influenced language of forms that discreetly recalls the noble table silver of modern grand hotels. Both the form of this service and the infinite possibilities it offers are unique – not only for MEISSEN®, but also for the culture of fine dining in general.

MEISSEN® COSMOPOLITAN is also appealing because its surfaces are designed in a totally new and sensual style, with a spectrum ranging from classical white and lush gold through precious platinum to mesh textures

and unconventionally sketched décors. Sleekly simple today, daringly eccentric tomorrow? MEISSEN® COSMOPOLITAN is the service for individualists – for people who love specialness. Be your own designer and create your own personal accents – newly each day! Draw upon the diversity of the decorative worlds of MEISSEN® COSMOPOLITAN and create your uniquely individual table arrangement to suit the momentary mood and occasion.

MEISSEN® COSMOPOLITAN: one table service, unlimited possibilities.







THE BUILDING BLOCKS

Modern, elegant and wonderfully versatile. MEISSEN® COSMOPOLITAN changes the way we think about dining services. It provides the freedom and flexibility to create new combinations every day depending on the occasion and atmosphere. You can use it as a complete service or put together individual pieces and so enjoy endless possibilities and functions with just a few pieces.



ESPRESSO SAUCER
Ø 12.5 cm, 4 7/8”
37559



TEA SAUCER
Ø 16.5 cm, 6 1/2”
37613



COFFEE SAUCER
Ø 16.5 cm, 6 1/2”
37562



ESPRESSO CUP
V 0.05 l, 1 3/4 oz
37569



TEA CUP
V 0.20 l, 7 oz
37623



COFFEE CUP
V 0.20 l, 7 oz
37572



BOWL
Ø 6 cm, 2 3/8”
37190



BOWL
Ø 8 cm, 3 1/8”
37191



BOWL
Ø 10 cm, 4”
37192



SCENTED CANDLE
Ø 6 cm, 2 3/8”
37M02



CREAMER
V 0.15 l, 5 1/4 oz
37762



EGG CUP
H 4.7 cm, 1 7/8”
37179



**CAPPUCCINO SAUCER
BREAD PLATE**
Ø 18 cm, 7 1/8”
37564



PLATE, FLAT
Ø 20 cm, 7 7/8”
37071



DINNER PLATE
Ø 24 cm, 9 1/2”
37475



CAPPUCCINO CUP
V 0.20 l, 7 oz
37574



BOWL
Ø 12.5 cm, 4 7/8”
37438



BOWL
Ø 16.5 cm, 6 1/2”
37439



BOWL
Ø 10 cm, 4”
37192



**SOUP BOWL
WITH HANDLES**
V 0.30 l, 10 1/2 oz
37061



CAVIAR DISH
Ø 16.5 cm, 6 1/2”
37066



SUGAR BOWL
H 8 cm, 3 1/8”
37823



SOUP PLATE
Ø 20.5 cm, 8 1/8”
37488



CREAMER
V 0.30 l, 10 1/2 oz
37764



THE BUILDING BLOCKS

The platters and plates of MEISSEN® COSMOPOLITAN let you create many different arrangements: for hors d'oeuvres, desserts or as atmospheric table decorations with fragrant candles. The lengths and diameters of each individual element harmonise with the proportions of all the others.



SMALL DISH, SQUARE
L 9 cm, 3 1/2"
53578



SMALL DISH, SQUARE
L 13 cm, 5 1/8"
53579



PLATTER, SQUARE
L 17 cm, 6 5/8"
37275



BOWL
Ø 8 cm, 3 1/8"
37191



BOWLS
Ø 6 cm, 2 3/8"
37190



BOWLS
Ø 8 cm, 3 1/8"
37191



SCENTED CANDLE
Ø 6 cm, 2 3/8"
37M02



EGG CUPS
H 4.7 cm, 1 7/8"
37179



PLATTER, SQUARE
L 21 cm, 8 1/4"
37276



BOWLS
Ø 10 cm, 4"
37192



PLATTER, SQUARE
L 25 cm, 9 7/8"
37277



BOWLS
Ø 12.5 cm, 4 7/8"
37438





THE DÉCOR WORLDS

From pure white, through gold and platinum, to the vibrant colours of Royal Palace and the Miami Style; or the fine and artistic draughtsmanship of Blue Orchid or the Ming dragon: the noble décors of MEISSEN® COSMOPOLITAN are as diverse as your taste.



ROYAL PALACE
BLACK 24



ROYAL PALACE
TURQUOISE 28



ROYAL PALACE
WHITE 32



ROYAL PALACE
RED 36



WHITE / MESH WHITE 40



PLATINUM /
MESH PLATINUM 56



GOLD / MESH GOLD 70



BLUE ORCHID PLATINUM 86



BLUE ORCHID
MESH WHITE 94



BLACK MING DRAGON
PLATINUM 100



MIAMI STYLE
TURQUOISE SEA 114



MIAMI STYLE
RED SUNSET 116

THE DÉCOR WORLDS

Create your own look every day with MEISSEN® COSMOPOLITAN – the many décors offer all kinds of possibilities and match each other perfectly.

BASIC



WHITE
Décor 000001



MESH WHITE
Décor 79A365

PRECIOUS METAL



GOLD
Décor 99A114



MESH-GOLD
Décor 79A165



PLATIN
Décor 99A214



MESH-PLATIN
Décor 79A265



ROYAL PALACE



ROYAL PALACE
BLACK
Décor 79A473



ROYAL PALACE
TURQUOISE
Décor 79A471



ROYAL PALACE
WHITE
Décor 79A475



ROYAL PALACE
RED
Décor 79A470

BLUE ORCHID



BLUE ORCHID
PLATINUM
Décor 79A268



BLUE ORCHID
MESH WHITE
Décor 79A465

MING DRAGON



BLACK
MING DRAGON
PLATINUM
Décor 33A090

MIAMI STYLE



MIAMI STYLE
TURQUOISE SEA
Décor 997021





MIAMI STYLE
RED SUNSET
Décor 998021

MEISSEN® COSMOPOLITAN ROYAL PALACE BLACK TURQUOISE WHITE RED

For “Royal Palace”, we returned to the place where it all began three centuries ago: Albrechtsburg in Meissen, where our merchandise was manufactured for 150 years. The castle’s historic mosaic floors provided the inspiration for the geometrically modern décor of “Royal Palace”. In elegant black, stylish turquoise, sublime white and lush red, this graphic pattern regally celebrates the high art of fine dining.





HISTORICAL PATTERN: THE GEOMETRIC DÉCOR OF ROYAL PALACE IS INSPIRED BY THE MOSAIC FLOORS OF ALBRECHTSBURG IN MEISSEN, THE HOME AND PRODUCTION SITE OF THE MEISSEN MANUFACTORY UNTIL 1863.

SETS MEISSEN® COSMOPOLITAN ROYAL PALACE BLACK



COFFEE SET
8-piece set: 2 coffee cups with golden rim,
1 creamer, 1 sugar bowl in gold; 2 saucers
and 2 plates in Royal Palace Black
79A482-C3703-1



TEA SET
8-piece set: 2 tea cups with golden rim,
1 sugar bowl and 1 pot in gold; 2 saucers
and 2 plates in Royal Palace Black
79A482-C3704-1



ESPRESSO SET
4-piece set: 2 espresso cups
with golden rim, 2 saucers in
Royal Palace Black
79A482-C3701-1



COFFEE SET
8-piece set: 2 coffee cups, 1 creamer and
1 sugar bowl in gold; 2 saucers and 2 plates
in Royal Palace Black
79A483-C3703-1



TEA SET
8-piece set: 2 tea cups, 1 sugar bowl
and 1 pot in gold; 2 saucers and
2 plates in Royal Palace Black
79A483-C3704-1



ESPRESSO SET
4-piece set: 2 espresso cups
in gold with 2 saucers in
Royal Palace Black
79A483-C3701-1



COLLECTION MEISSEN® COSMOPOLITAN

ROYAL PALACE BLACK

PLATES



BREAD PLATE
Ø 18 cm, 7 1/8" · 79A473-37564-1



STARTER PLATE
Ø 22.5 cm, 8 7/8" · 79A473-37473-1



DINNER PLATE
Ø 24 cm, 9 1/2" · 79A474-37475-1



DINNER PLATE
Ø 30 cm, 11 3/4" · 79A473-37479-1



SOUP PLATE
Ø 20.5 cm, 8 1/8" · 98A077-37487-1

DISHES, PLATTERS AND ACCESSORIES



SMALL DISH
L 9 cm, 3 1/2" · 79A473-53578-1



PLATTER
L 17 cm, 6 5/8" · 79A473-37275-1



PLATTER
L 21 cm, 8 1/4" · 79A473-37276-1



PLATTER
L 27 cm, 10 5/8" · 79A473-37510-1



PLATTER
L 25 cm, 9 7/8" · 98A077-37277-1



PLATTER
L 32 cm, 12 5/8" · 98A077-37308-1



EGG CUP
H 4.7 cm, 1 7/8" · 98A077-37179-1

All products marked with décor number 98A077 have a slender golden border that perfectly harmonises with the Royal Palace Black décor.

COFFEE AND TEA



ESPRESSO SAUCER
Ø 12.5 cm, 4 7/8" · 79A473-37559-1



ESPRESSO CUP
V 0.05 l, 1 3/4 oz · 98A077-37569-1



COFFEE SAUCER
Ø 16.5 cm, 6 1/2" · 79A473-37562-1



COFFEE CUP
V 0.20 l, 7 oz · 98A077-37572-1



CAPPUCCINO SAUCER
Ø 18 cm, 7 1/8" · 79A473-37564-1



CAPPUCCINO CUP
V 0.20 l, 7 oz · 98A077-37574-1



TEA SAUCER
Ø 16.5 cm, 6 1/2" · 79A473-37613-1



TEA CUP
V 0.20 l, 7 oz · 98A077-37623-1

The Royal Palace table service is dishwasher-safe.

SETS MEISSEN® COSMOPOLITAN

ROYAL PALACE TURQUOISE



COFFEE SET
8-piece set: 2 coffee cups with red rim, 1 creamer and 1 sugar bowl in white; 2 saucers and 2 plates in Royal Palace Turquoise
79A480-C3703-1



TEA SET
8-piece set: 2 tea cups with red rim, 1 sugar bowl and 1 pot in white; 2 saucers and 2 plates in Royal Palace Turquoise
79A480-C3704-1



ESPRESSO SET
4-piece set: 2 espresso cups with red rim, 2 saucers in Royal Palace Turquoise
79A480-C3701-1



COFFEE SET
8-piece set: 2 coffee cups in platinum, 1 creamer and 1 sugar bowl in white; 2 saucers and 2 plates in Royal Palace Turquoise
79A481-C3703-1



TEA SET
8-piece set: 2 tea cups in platinum, 1 sugar bowl and 1 pot in white; 2 saucers and 2 plates in Royal Palace Turquoise
79A481-C3704-1



ESPRESSO SET
4-piece set: 2 espresso cups in platinum with 2 saucers in Royal Palace Turquoise
79A481-C3701-1

COLLECTION MEISSEN® COSMOPOLITAN

ROYAL PALACE TURQUOISE

PLATES



BREAD PLATE
Ø 18 cm, 7 1/8" · 79A471-37564-1



STARTER PLATE
Ø 22.5 cm, 8 7/8" · 79A471-37473-1



DINNER PLATE
Ø 24 cm, 9 1/2" · 79A472-37475-1



DINNER PLATE
Ø 30 cm, 11 3/4" · 79A471-37479-1



SOUP PLATE
Ø 20.5 cm, 8 1/8" · 98A076-37487-1

DISHES, PLATTERS AND ACCESSORIES



SMALL DISH
L 9 cm, 3 1/2" · 79A471-53578-1



PLATTER
L 17 cm, 6 5/8" · 79A471-37275-1



PLATTER
L 21 cm, 8 1/4" · 79A471-37276-1



PLATTER
L 25 cm, 9 7/8" · 79A471-37510-1



PLATTER
L 25 cm, 9 7/8" · 98A076-37277-1



PLATTER
L 32 cm, 12 5/8" · 98A076-37308-1



EGG CUP
H 4.7 cm, 1 7/8" · 98A076-37179-1

COFFEE AND TEA



ESPRESSO SAUCER
Ø 12.5 cm, 4 7/8" · 79A471-37559-1



ESPRESSO CUP
V 0.05 l, 1 3/4 oz · 98A076-37569-1



COFFEE SAUCER
Ø 16.5 cm, 6 1/2" · 79A471-37562-1



COFFEE CUP
V 0.20 l, 7 oz · 98A076-37572-1



CAPPUCCINO SAUCER
Ø 18 cm, 7 1/8" · 79A471-37564-1



CAPPUCCINO CUP
V 0.20 l, 7 oz · 98A076-37574-1



TEA SAUCER
Ø 16.5 cm, 6 1/2" · 79A471-37613-1



TEA CUP
V 0.20 l, 7 oz · 98A076-37623-1

All products with décor number 98A076 have a slender red border that perfectly harmonises with the Royal Palace Turquoise décor.

The Royal Palace table service is dishwasher-safe.



SETS MEISSEN® COSMOPOLITAN
ROYAL PALACE WHITE



COFFEE SET
8-piece set: 2 coffee cups, 1 creamer
and 1 sugar bowl in white; 2 saucers and
2 plates in Royal Palace White
79A484-C3703-1



TEA SET
8-piece set: 2 tea cups, 1 sugar bowl
and 1 pot in white; 2 saucers and 2 plates
in Royal Palace White
79A484-C3704-1



ESPRESSO SET
4-piece set: 2 espresso cups
in white with 2 saucers in
Royal Palace White
79A484-C3701-1



COFFEE SET
8-piece set: 2 coffee cups in platinum,
1 creamer and 1 sugar bowl in white; 2 saucers
and 2 plates in Royal Palace White
79A485-C3703-1



TEA SET
8-piece set: 2 tea cups in platinum,
1 sugar bowl and 1 pot in white; 2 saucers
and 2 plates in Royal Palace White
79A485-C3704-1



ESPRESSO SET
4-piece set: 2 espresso cups
in platinum with 2 saucers in
Royal Palace White
79A485-C3701-1

COLLECTION MEISSEN® COSMOPOLITAN
ROYAL PALACE WHITE

PLATES AND SAUCERS



BREAD PLATE
Ø 18 cm, 7 1/8" · 79A475-37564-1



STARTER PLATE
Ø 22.5 cm, 8 7/8" · 79A475-37473-1



DINNER PLATE
Ø 24 cm, 9 1/2" · 79A476-37475-1



DINNER PLATE
Ø 30 cm, 11 3/4" · 79A475-37479-1



ESPRESSO SAUCER
Ø 12.5 cm, 4 7/8" · 79A475-37559-1



COFFEE SAUCER
Ø 16.5 cm, 6 1/2" · 79A475-37562-1



CAPPUCCINO SAUCER
Ø 18 cm, 7 1/8" · 79A475-37564-1



TEA SAUCER
Ø 16.5 cm, 6 1/2" · 79A475-37613-1

DISHES AND PLATTERS




SMALL DISH
L 9 cm, 3 1/2" · 79A475-53578-1



PLATTER
L 17 cm, 6 5/8" · 79A475-37275-1



PLATTER
L 21 cm, 8 1/4" · 79A475-37276-1



PLATTER
L 27 cm, 10 5/8" · 79A475-37510-1

The Royal Palace table service is dishwasher-safe.





SETS MEISSEN® COSMOPOLITAN
ROYAL PALACE RED



COFFEE SET
8-piece set: 2 coffee cups with golden rim,
1 creamer and 1 sugar bowl in gold; 2 saucers
and 2 plates in Royal Palace Red
79A486-C3703-1



TEA-SET
8-piece set: 2 tea cups with golden rim;
1 sugar bowl and 1 pot in gold; 2 saucers
and 2 plates in Royal Palace Red
79A486-C3704-1



ESPRESSO SET
4-piece set: 2 espresso cups
with golden rim, 2 saucers in
Royal Palace Red
79A486-C3701-1



COFFEE SET
8-piece set: 2 coffee cups, 1 creamer
and 1 sugar bowl in gold; 2 saucers and
2 plates in Royal Palace Red
79A487-C3703-1



TEA-SET
8-piece set: 2 tea cups, 1 sugar bowl
and 1 pot in gold; 2 saucers and 2 plates
in Royal Palace Red
79A487-C3704-1



ESPRESSO SET
4-piece set: 2 espresso cups
in gold with 2 saucers in
Royal Palace Red
79A487-C3701-1

COLLECTION MEISSEN® COSMOPOLITAN
ROYAL PALACE RED

PLATES AND SAUCERS



BREAD PLATE
Ø 18 cm, 7 1/8" · 79A470-37564-1



STARTER PLATE
Ø 22.5 cm, 8 7/8" · 79A470-37473-1



DINNER PLATE
Ø 24 cm, 9 1/2" · 79A470-37475-1



DINNER PLATE
Ø 30 cm, 11 3/4" · 79A470-37479-1



ESPRESSO SAUCER
Ø 12.5 cm, 4 7/8" · 79A470-37559-1



COFFEE SAUCER
Ø 16.5 cm, 6 1/2" · 79A470-37562-1



CAPPUCCINO SAUCER
Ø 18 cm, 7 1/8" · 79A470-37564-1



TEA SAUCER
Ø 16.5 cm, 6 1/2" · 79A470-37613-1

DISHES AND PLATTERS



SMALL DISH
L 9 cm, 3 1/2" · 79A470-53578-1



PLATTER
L 17 cm, 6 5/8" · 79A470-37275-1



PLATTER
L 21 cm, 8 1/4" · 79A470-37276-1



PLATTER
L 27 cm, 10 5/8" · 79A470-37510-1

The Royal Palace table service is dishwasher-safe.



MEISSEN® COSMOPOLITAN WHITE / MESH WHITE

Always modern. Timelessly beautiful. Classic, fine and pure. Either plain or with a delicate Mesh structure, white is a clear acknowledgement. A statement. Sometimes exquisite taste can be enchantingly simple.





MEISSEN® COSMOPOLITAN WHITE

SETS MEISSEN® COSMOPOLITAN WHITE



STARTER SET

27-piece set: 2 tea cups, 2 coffee cups, 2 egg cups,
3 x 2 saucers, 5 x 2 plates in various sizes,
2 bowls, 1 creamer, 1 pot, 1 sugar bowl in white
000001-C3708-1



COFFEE SET

8-piece set: 2 coffee cups,
2 saucers, 2 plates, 1 creamer
and 1 sugar bowl in white
000001-C3703-1



BREAKFAST SET

5-piece set: 1 cappuccino cup with 1 saucer,
1 plate, 1 dessert dish with 1 saucer in white
000001-C3702-1



ESPRESSO SET

4-piece set: 2 espresso cups
with 2 saucers in white
000001-C3701-1



TEA SET

8-piece set: 2 tea cups, 2 saucers, 2 plates,
1 pot and 1 sugar bowl in white
000001-C3704-1



SUSHI SET

5-piece set: 1 large sushi platter, 1 knife holder,
1 dish in white, 2 chopsticks
000001-C3705-1



DIP SET

5-piece set: 4 bowls and 1 platter
(width 17 cm, 6 5/8”) in white
000001-C3707-1



EGG CUP SET

2-piece set: 2 egg cups in white
000001-C3706-1



CAVIAR DISH SET

Including glass dish
000001-C3711-1



TEALIGHT SET

5-piece set: 4 scented candles,
fragrance “Velvet Skin”, 1 platter
(width: 13 cm, 5 1/8”) in white
000001-C3709-1

MEISSEN® COSMOPOLITAN WHITE

PLATES



BREAD PLATE
Ø 18 cm, 7 1/8" · 000001-37564-1



PLATE
Ø 20 cm, 7 7/8" · 000001-37071-1



STARTER PLATE
Ø 22.5 cm, 8 7/8" · 000001-37473-1



DINNER PLATE
Ø 24 cm, 9 1/2" · 000001-37475-1



GOURMET PLATE
Ø 28.5 cm, 11 1/4" · 000001-37480-1



DINNER PLATE
Ø 30 cm, 11 3/4" · 000001-37479-1



SERVICE PLATE
Ø 32.5 cm, 12 3/4" · 000001-37478-1



SOUP PLATE
Ø 20.5 cm, 8 1/8" · 000001-37487-1



SOUP PLATE WITH WIDE RIM
Ø 20.5 cm, 8 1/8" · 000001-37488-1



GOURMET PLATE DEEP
Ø 26 cm, 10 1/4" · 000001-37489-1

PLATTERS



PLATTER
L 25 cm, 9 7/8" · 000001-37307-1



PLATTER
L 32 cm, 12 5/8" · 000001-37308-1



DISHES AND PLATTERS



SMALL DISH
L 9 cm, 3 1/2" · 000001-53578-1



SMALL DISH
L 13 cm, 5 1/8" · 000001-53579-1



PLATTER
L 17 cm, 6 5/8" · 000001-37275-1



PLATTER
L 21 cm, 8 1/4" · 000001-37276-1




PLATTER
L 25 cm, 9 7/8" · 000001-37277-1



TRAY WITH LEATHER BOTTOM
L 25 cm, 9 7/8" · 000001-37M01-1



SUSHI PLATTER
L 27 cm, 10 5/8" · 000001-37509-1



SUSHI PLATTER
L 27 cm, 10 5/8" · 000001-37510-1

BOWLS



BOWL
Ø 6 cm, 2 3/8" · 000001-37190-1



BOWL
Ø 8 cm, 3 1/8" · 000001-37191-1



BOWL
Ø 10 cm, 4" · 000001-37192-1



BOWL
Ø 12.5 cm, 4 7/8" · 000001-37438-1



BOWL
Ø 16.5 cm, 6 1/2" · 000001-37439-1



BOWL
Ø 21 cm, 8 1/4" · 000001-37440-1



TUREEN
Ø 25.5 cm, 10" · 000001-37022-1

ACCESSORIES



KNIFE HOLDER
L 8 cm, 3 1/8" · 000001-37238-1



SALT SHAKER
H 5.5 cm, 2 1/8" · 000001-37M03-1



PEPPER SHAKER
H 5.5 cm, 2 1/8" · 000001-37M04-1



EGG CUP
H 4.7 cm, 1 7/8" · 000001-37179-1



CAVIAR DISH, COMPLETE
Ø 16.5 cm, 6 1/2" · 000001-37076-1



BOTTOM FOR CAVIAR DISH
Ø 16.5 cm, 6 1/2" · 000001-37066-1



RING FOR CAVIAR DISH
Ø 16.5 cm, 6 1/2" · 000001-37056-1



SMALL GLASS BOWL FOR CAVIAR DISH
Ø 10.3 cm, 4" · XKRO01-XK090-1



SMALL GLASS BOWL FOR CAVIAR DISH, PLATINUM
Ø 10.3 cm, 4" · XKRO03-XK090-1



SMALL GLASS BOWL FOR CAVIAR DISH, GOLD
Ø 10.3 cm, 4" · XKRO02-XK090-1



SOUP BOWL
V 0.30 l, 10 1/2 oz · 000001-37081-1





MEISSEN® COSMOPOLITAN WHITE

COFFEE AND TEA



ESPRESSO CUP, COMPLETE
V 0.05 l, 1 3/4 oz · 000001-37579-1



COFFEE CUP, COMPLETE
V 0.20 l, 7 oz · 000001-37582-1



CAPPUCCINO CUP, COMPLETE
V 0.20 l, 7 oz · 000001-37584-1



TEA CUP, COMPLETE
V 0.20 l, 7 oz · 000001-37633-1



ESPRESSO SAUCER
Ø 12.5 cm, 4 7/8" · 000001-37559-1



ESPRESSO CUP
V 0.05 l, 1 3/4 oz · 000001-37569-1



COFFEE SAUCER
Ø 16.5 cm, 6 1/2" · 000001-37562-1



COFFEE CUP
V 0.20 l, 7 oz · 000001-37572-1



CAPPUCCINO SAUCER
Ø 18 cm, 7 1/8" · 000001-37564-1



CAPPUCCINO CUP
V 0.20 l, 7 oz · 000001-37574-1



TEA SAUCER
Ø 16.5 cm, 6 1/2" · 000001-37613-1



TEA CUP
V 0.20 l, 7 oz · 000001-37623-1



CREAMER
V 0.15 l, 5 1/4 oz · 000001-37762-1



CREAMER
V 0.30 l, 10 1/2 oz · 000001-37764-1



POT
V 0.6 l, 21 1/8 oz · 000001-37726-1



POT
V 1.0 l, 35 1/4 oz · 000001-37727-1



SUGAR BOWL
H 8 cm, 3 1/8" · 000001-37823-1



MEISSEN® COSMOPOLITAN MESH WHITE

SETS MEISSEN® COSMOPOLITAN MESH WHITE



COFFEE SET
8-piece set: 2 coffee cups, 1 creamer and 1 sugar bowl in white, 2 saucers and 2 plates in Mesh white
79A365-C3703-1



COFFEE SET
4-piece set: 2 coffee cups in white with 2 saucers in Mesh white
79A365-C3712-1



CAPPUCCINO CUP SET
2-piece set: 1 cappuccino cup in white with 1 saucer in Mesh white
79A365-C3710-1



ESPRESSO SET
4-piece set: 2 espresso cups in white with 2 saucers in Mesh white
79A365-C3701-1



TEA SET
8-piece set: 2 tea cups, 1 pot, 1 sugar bowl in white, 2 saucers and 2 plates in Mesh white
79A365-C3704-1



TEA SET
4-piece set: 2 tea cups in white with 2 saucers in Mesh white
79A365-C3713-1

COLLECTION MEISSEN® COSMOPOLITAN MESH WHITE

PLATES AND SAUCERS



PLATE
Ø 20 cm, 7 7/8" · 79A365-37071-1



STARTER PLATE
Ø 22.5 cm, 8 7/8" · 79A365-37473-1



DINNER PLATE
Ø 24 cm, 9 1/2" · 79A365-37475-1



DINNER PLATE
Ø 30 cm, 11 3/4" · 79A365-37479-1



SOUP PLATE
Ø 20.5 cm, 8 1/8" · 79A365-37487-1



ESPRESSO SAUCER
Ø 12.5 cm, 4 7/8" · 79A365-37559-1



COFFEE SAUCER
Ø 16.5 cm, 6 1/2" · 79A365-37562-1



CAPPUCCINO SAUCER
Ø 18 cm, 7 1/8" · 79A365-37564-1



TEA SAUCER
Ø 16.5 cm, 6 1/2" · 79A365-37613-1

The COSMOPOLITAN Mesh White table service is dishwasher-safe.



MEISSEN® COSMOPOLITAN PLATINUM / MESH PLATINUM

Clear, rare, timelessly beautiful. Platinum stands for real values. With an expressive platinum background or the playful Mesh Platinum décor, its discreet aura inspires people who love the special things in life. Porcelain with platinum – a service for true aesthetes.



MEISSEN® COSMOPOLITAN PLATINUM
(SOLID / MESH)



POT WITH PLATINUM DÉCOR
V 0.6 l, 21 1/8 oz · 99A214-37726-1



SETS MEISSEN® COSMOPOLITAN PLATINUM



STARTER SET

27-piece set: 2 tea cups, 2 coffee cups, 1 creamer, 1 pot, 1 sugar bowl, 2 plates (Ø 24 cm, 9 1/2"), 2 bowls and 2 egg cups in platinum each; 3 x 2 saucers and 8 plates (2 x Ø 20 cm, 7 7/8"; 2 x Ø 20.5 cm, 8 1/8"; 2 x Ø 22.5 cm, 8 7/8"; 2 x Ø 30 cm, 11 3/4") in Mesh Platinum
99A214-C3708-1



COFFEE SET

8-piece set: 2 coffee cups, 1 creamer, 1 sugar bowl in platinum; 2 saucers and 2 plates in Mesh Platinum
99A214-C3703-1



ESPRESSO SET

4-piece set: 2 espresso cups in platinum with 2 saucers in Mesh Platinum
99A214-C3701-1



TEA SET

8-piece set: 2 tea cups, 1 sugar bowl, 1 pot in platinum; 2 saucers and 2 plates in Mesh Platinum
99A214-C3704-1



CAVIAR DISH SET

Including small glass bowl
99A214-C3711-1



COLLECTION MEISSEN® COSMOPOLITAN PLATINUM

PLATES



BREAD PLATE
Ø 18 cm, 7 1/8" · 99A214-37564-1



PLATE
Ø 20 cm, 7 7/8" · 99A214-37071-1



STARTER PLATE
Ø 22.5 cm, 8 7/8" · 99A214-37473-1



DINNER PLATE
Ø 24 cm, 9 1/2" · 99A214-37475-1



DINNER PLATE
Ø 30 cm, 11 3/4" · 99A214-37479-1



SOUP PLATE
Ø 20.5 cm, 8 1/8" · 99A214-37487-1



DISHES AND PLATTERS



SMALL DISH
L 9 cm, 3 1/2" · 99A214-53578-1



SMALL DISH
L 13 cm, 5 1/8" · 99A214-53579-1



PLATTER
L 17 cm, 6 5/8" · 99A214-37275-1



PLATTER
L 21 cm, 8 1/4" · 99A214-37276-1



PLATTER
L 25 cm, 9 7/8" · 99A214-37277-1



TRAY WITH
LEATHER BOTTOM
L 25 cm, 9 7/8" · 99A214-37M01-1



SUSHI PLATTER
L 27 cm, 10 5/8" · 99A214-37509-1



PLATTER
L 25 cm, 9 7/8" · 99A214-37307-1



PLATTER
L 32 cm, 12 5/8" · 99A214-37308-1

ACCESSORIES



KNIFE HOLDER
L 8 cm, 3 1/8" · 99A214-37238-1





COLLECTION MEISSEN® COSMOPOLITAN PLATINUM

COFFEE AND TEA



ESPRESSO CUP, COMPLETE
V 0.05 l, 1 3/4 oz · 99A214-37579-1



COFFEE CUP, COMPLETE
V 0.20 l, 7 oz · 99A214-37582-1



CAPPUCCINO CUP, COMPLETE
V 0.20 l, 7 oz · 99A214-37584-1



TEA CUP, COMPLETE
V 0.20 l, 7 oz · 99A214-37633-1



ESPRESSO SAUCER
Ø 12.5 cm, 4 7/8" · 99A214-37559-1



ESPRESSO CUP
V 0.05 l, 1 3/4 oz · 99A214-37569-1



COFFEE SAUCER
Ø 16.5 cm, 6 1/2" · 99A214-37562-1



COFFEE CUP
V 0.20 l, 7 oz · 99A214-37572-1



CAPPUCCINO SAUCER
Ø 18 cm, 7 1/8" · 99A214-37564-1



CAPPUCCINO CUP
V 0.20 l, 7 oz · 99A214-37574-1



TEA SAUCER
Ø 16.5 cm, 6 1/2" · 99A214-37613-1



TEA CUP
V 0.20 l, 7 oz · 99A214-37623-1



CREAMER
V 0.15 l, 5 1/4 oz · 99A214-37762-1



CREAMER
V 0.30 l, 10 1/2 oz · 99A214-37764-1



POT
V 0.6 l, 21 1/8 oz · 99A214-37726-1



POT
V 1.0 l, 35 1/4 oz · 99A214-37727-1



SUGAR BOWL
H 8 cm, 3 1/8" · 99A214-37823-1

COLLECTION MEISSEN® COSMOPOLITAN PLATIN

BOWLS



BOWL
Ø 6 cm, 2 3/8" · 99A214-37190-1



BOWL
Ø 8 cm, 3 1/8" · 99A214-37191-1



BOWL
Ø 10 cm, 4" · 99A214-37192-1



BOWL
Ø 12.5 cm, 4 7/8" · 99A214-37438-1



BOWL
Ø 16.5 cm, 6 1/2" · 99A214-37439-1



BOWL
Ø 21 cm, 8 1/4" · 99A214-37440-1

ACCESSORIES



SOUP BOWL, COMPLETE
V 0.30 l, 10 1/2 oz
99A214-37081-1



SALT SHAKER
H 5.5 cm, 2 1/8"
99A214-37M03-1



PEPPER SHAKER
H 5.5 cm, 2 1/8"
99A214-37M04-1



EGG CUP
H 4.7 cm, 1 7/8"
99A214-37179-1



CAVIAR DISH, COMPLETE
Ø 16.5 cm, 6 1/2"
99A214-37076-1



BOTTOM FOR CAVIAR DISH
Ø 16.5 cm, 6 1/2"
99A214-37066-1



SMALL GLASS BOWL FOR CAVIAR DISH
Ø 10.3 cm, 4"
XKRO03-XK090-1



RING FOR CAVIAR DISH
Ø 16.5 cm, 6 1/2"
99A214-37056-1

SETS MEISSEN® COSMOPOLITAN MESH PLATINUM



STARTER SET
27-piece set: 2 tea cups, 2 coffee cups, 1 creamer, 1 pot, 1 sugar bowl, 2 plates (Ø 24 cm, 9 1/2"), 2 bowls and 2 egg cups in white each; 3 x 2 saucers and 8 plates (2 x Ø 20 cm, 7 7/8"; 2 x Ø 20.5 cm, 8 1/8", 2 x Ø 22.5 cm, 8 7/8"; 2 x Ø 30 cm, 11 3/4") in Mesh Platinum
79A265-C3708-1



COFFEE SET
8-piece set: 2 coffee cups, 1 creamer, 1 sugar bowl in white; 2 saucers and 2 plates in Mesh Platinum
79A265-C3703-1



ESPRESSO SET
4-piece set: 2 espresso cups in white with 2 saucers in Mesh Platinum
79A265-C3701-1



TEA SET
8-piece set: 2 tea cups, 1 pot, 1 sugar bowl in white; 2 saucers and 2 plates in Mesh Platinum
79A265-C3704-1

COLLECTION MEISSEN® COSMOPOLITAN MESH PLATINUM

PLATES AND SAUCERS



PLATE
Ø 20 cm, 7 7/8" · 79A265-37071-1



STARTER PLATE
Ø 22.5 cm, 8 7/8" · 79A265-37473-1



DINNER PLATE
Ø 24 cm, 9 1/2" · 79A265-37475-1



DINNER PLATE
Ø 30 cm, 11 3/4" · 79A265-37479-1



SOUP PLATE
Ø 20.5 cm, 8 1/8" · 79A266-37487-1



ESPRESSO SAUCER
Ø 12.5 cm, 4 7/8" · 79A265-37559-1



COFFEE SAUCER
Ø 16.5 cm, 6 1/2" · 79A265-37562-1



CAPPUCCINO SAUCER
Ø 18 cm, 7 1/8" · 79A265-37564-1



TEA SAUCER
Ø 16.5 cm, 6 1/2" · 79A265-37613-1

ACCESSORIES



CAVIAR DISH, RING WITH
MESH PLATINUM DÉCOR
BOTTOM IN WHITE
Ø 16.5 cm, 6 1/2" · 79A265-37076-1



CAVIAR DISH, RING WITH
MESH PLATINUM DÉCOR
BOTTOM IN PLATINUM
DÉCOR
Ø 16.5 cm, 6 1/2" · 79A267-37076-1



GLASSCHÄLCHEN
FÜR KAVIARSCHALE
Ø 10,3 cm · XKRO03-XK090-1



RING FOR CAVIAR DISH
Ø 16.5 cm, 6 1/2" · 79A265-37056-1





MEISSEN® COSMOPOLITAN GOLD / MESH GOLD

The fine gold background applied by hand is rich and warm and radiates cheerfulness, opulence and pure desire for luxury. The matching décor in Mesh Gold provides sensuous understatement and can be combined beautifully with gold or white. There remains only one thing for you to do: bask in the colours, take some time out and enjoy it with all your senses.



MEISSEN® COSMOPOLITAN GOLD



STARTER PLATE
WITH GOLD DÉCOR
Ø 22.5 cm, 8 7/8" · 99A114-37473-1



SETS MEISSEN® COSMOPOLITAN GOLD



STARTER SET

27-piece set: 2 tea cups, 2 coffee cups, 1 creamer, 1 pot, 1 sugar bowl,
2 plates (Ø 24 cm, 9 1/2"), 2 bowls and 2 egg cups in gold each; 3 x 2 saucers,
8 plates (2 x Ø 20 cm, 7 7/8"; 2 x Ø 20.5 cm, 8 1/8"; 2 x Ø 22.5 cm, 8 7/8";
2 x Ø 30 cm, 11 3/4") in Mesh Gold
99A114-C3708-1



COFFEE SET

8-piece set: 2 coffee cups, 1 creamer,
1 sugar bowl in gold; 2 saucers
and 2 plates in Mesh Gold
99A114-C3703-1



ESPRESSO SET

4-piece set: 2 espresso cups in gold
with 2 saucers in Mesh Gold
99A114-C3701-1



TEA SET

8-piece set: 2 tea cups, 1 sugar bowl
1 pot in gold; 2 saucers and 2 plates
in Mesh Gold
99A114-C3704-1



CAVIAR DISH SET

Including small glass bowl
99A114-C3711-1



PLATES



BREAD PLATE
Ø 18 cm, 7 1/8" · 99A114-37564-1



PLATE
Ø 20 cm, 7 7/8" · 99A114-37071-1



STARTER PLATE
Ø 22.5 cm, 8 7/8" · 99A114-37473-1



DINNER PLATE
Ø 24 cm, 9 1/2" · 99A114-37475-1



DINNER PLATE
Ø 30 cm, 11 3/4" · 99A114-37479-1



SOUP PLATE
Ø 20.5 cm, 8 1/8" · 99A114-37487-1



DISHES AND PLATTERS



SMALL DISH
L 9 cm, 3 1/2" · 99A114-53578-1



SMALL DISH
L 13 cm, 5 1/8" · 99A114-53579-1



PLATTER
L 17 cm, 6 5/8" · 99A114-37275-1



PLATTER
L 21 cm, 8 1/4" · 99A114-37276-1



PLATTER
L 25 cm, 9 7/8" · 99A114-37277-1



TRAY WITH LEATHER BOTTOM
L 25 cm, 9 7/8" · 99A114-37M01-1



SUSHI PLATTER
L 27 cm, 10 5/8" · 99A114-37509-1



PLATTER
L 25 cm, 9 7/8" · 99A114-37307-1



PLATTER
L 32 cm, 12 5/8" · 99A114-37308-1

ACCESSORIES



KNIFE HOLDER
L 8 cm, 3 1/8" · 99A114-37238-1





COLLECTION MEISSEN® COSMOPOLITAN GOLD

COFFEE AND TEA



ESPRESSO CUP, COMPLETE
V 0.05 l, 1 3/4 oz · 99A114-37579-1



COFFEE CUP, COMPLETE
V 0.20 l, 7 oz · 99A114-37582-1



CAPPUCCINO CUP, COMPLETE
V 0.20 l, 7 oz · 99A114-37584-1



TEA CUP, COMPLETE
V 0.20 l, 7 oz · 99A114-37633-1



ESPRESSO SAUCER
Ø 12.5 cm, 4 7/8" · 99A114-37559-1



ESPRESSO CUP
V 0.05 l, 1 3/4 oz · 99A114-37569-1



COFFEE SAUCER
Ø 16.5 cm, 6 1/2" · 99A114-37562-1



COFFEE CUP
V 0.20 l, 7 oz · 99A114-37572-1



CAPPUCCINO SAUCER
Ø 18 cm, 7 1/8" · 99A114-37564-1



CAPPUCCINO CUP
V 0.20 l, 7 oz · 99A114-37574-1



TEA SAUCER
Ø 16.5 cm, 6 1/2" · 99A114-37613-1



TEA CUP
V 0.20 l, 7 oz · 99A114-37623-1



CREAMER
V 0.15 l, 5 1/4 oz · 99A114-37762-1



CREAMER
V 0.30 l, 10 1/2 oz · 99A114-37764-1



POT
V 0.6 l, 21 1/8 oz · 99A114-37726-1



POT
V 1.0 l, 35 1/4 oz · 99A114-37727-1



SUGAR BOWL
H 8 cm, 3 1/8" · 99A114-37823-1

COLLECTION MEISSEN® COSMOPOLITAN GOLD

BOWLS



BOWL
Ø 6 cm, 2 3/8" · 99A114-37190-1



BOWL
Ø 8 cm, 3 1/8" · 99A114-37191-1



BOWL
Ø 10 cm, 4" · 99A114-37192-1



BOWL
Ø 12.5 cm, 4 7/8" · 99A114-37438-1



BOWL
Ø 16.5 cm, 6 1/2" · 99A114-37439-1



BOWL
Ø 21 cm, 8 1/4" · 99A114-37440-1



TUREEN
Ø 25.5 cm, 10" · 99A114-37022-1

ACCESSORIES



SOUP BOWL, COMPLETE
V 0.30 l, 10 1/2 oz · 99A114-37081-1



SALT SHAKER
H 5.5 cm, 2 1/8" · 99A114-37M03-1



PEPPER SHAKER
H 5.5 cm, 2 1/8" · 99A114-37M04-1



EGG CUP
H 4.7 cm, 1 7/8" · 99A114-37179-1



CAVIAR DISH, COMPLETE
Ø 16.5 cm, 6 1/2" · 99A114-37076-1



BOTTOM FOR CAVIAR DISH
Ø 16.5 cm, 6 1/2" · 99A114-37066-1



**SMALL GLASS BOWL
FOR CAVIAR DISH**
Ø 10.3 cm, 4" · XKRO02-XK090-1



RING FOR CAVIAR DISH
Ø 16.5 cm, 6 1/2" · 99A114-37056-1



SETS MEISSEN® COSMOPOLITAN MESH GOLD



STARTER SET

27-piece set: 2 tea cups, 2 coffee cups, 1 creamer, 1 pot, 1 sugar bowl, 2 plates (Ø 24 cm, 9 1/2"), 2 bowls and 2 egg cups in white each; 3 x 2 saucers and 8 plates (2 x Ø 20 cm, 7 7/8"; 2 x Ø 20.5 cm, 8 1/8"; 2 x Ø 22.5 cm, 8 7/8"; 2 x Ø 30 cm, 11 3/4") in Mesh Gold
79A165-C3708-1



COFFEE SET

8-piece set: 2 coffee cups, 1 creamer, 1 sugar bowl in white; 2 saucers and 2 plates in Mesh Gold
79A165-C3703-1



ESPRESSO SET

4-piece set: 2 espresso cups in white with 2 saucers in Mesh Gold
79A165-C3701-1



TEA SET

8-piece set: 2 tea cups, 1 sugar bowl, 1 pot in white; 2 saucers and 2 plates in Mesh Gold
79A165-C3704-1

SETS MEISSEN® COSMOPOLITAN MESH GOLD

PLATES AND SAUCERS



PLATE

Ø 20 cm, 7 7/8" · 79A165-37071-1



STARTER PLATE

Ø 22.5 cm, 8 7/8" · 79A165-37473-1



DINNER PLATE

Ø 24 cm, 9 1/2" · 79A165-37475-1



DINNER PLATE

Ø 30 cm, 11 3/4" · 79A165-37479-1



SOUP PLATE

Ø 20.5 cm, 8 1/8" · 79A166-37487-1



ESPRESSO SAUCER

Ø 12.5 cm, 4 7/8" · 79A165-37559-1



COFFEE SAUCER

Ø 16.5 cm, 6 1/2" · 79A165-37562-1



CAPPUCCINO SAUCER

Ø 18 cm, 7 1/8" · 79A165-37564-1



TEA SAUCER

Ø 16.5 cm, 6 1/2" · 79A165-37613-1

ACCESSORIES



CAVIAR DISH RING WITH MESH GOLD DÉCOR, BOTTOM IN WHITE

Ø 16.5 cm, 6 1/2" · 79A165-37076-1



CAVIAR DISH RING WITH MESH GOLD DÉCOR, BOTTOM IN GOLD DÉCOR

Ø 16.5 cm, 6 1/2" · 79A167-37076-1



SMALL GLASS BOWL FOR CAVIAR DISH

Ø 10.3 cm, 4" · XKRO02-XK090-1



RING FOR CAVIAR DISH

Ø 16.5 cm, 6 1/2" · 79A165-37056-1

MEISSEN® COSMOPOLITAN BLUE ORCHID

We are always creating new things from the treasures in our archives, our own artistic heritage, and the “Blue Orchid” décor by MEISSEN® is part of this tradition. The beautifully painted cobalt blue flower is inspired by “Blue orchid on branch” from the 1970s. It is one of the most popular of the approx. 100 décors created by the brilliant Professor Heinz Werner for the Meissen manufactory. With “Blue Orchid”, MEISSEN® COSMOPOLITAN has incorporated an element of Werner’s motif and placed it at the heart of its Mesh Platinum décor. A minimalist Asian look that pays homage to a master of his art.





MEISSEN® COSMOPOLITAN BLUE ORCHID PLATINUM



ESPRESSO SAUCER IN
BLUE ORCHID PLATINUM
Ø 12.5 cm, 4 7/8" · 79A268-37559-1



SETS MEISSEN® COSMOPOLITAN
BLUE ORCHID PLATINUM



COFFEE SET
8-piece set: 2 coffee cups, 1 creamer,
1 sugar bowl in platinum; 2 saucers and 2 plates
in Blue Orchid platinum
79A368-C3703-1



COFFEE CUP SET
4-piece set: 2 coffee cups in platinum
with 2 saucers in Blue Orchid platinum
79A368-C3712-1



ESPRESSO CUP SET
4-piece set: 2 espresso cups in platinum
with 2 saucers in Blue Orchid platinum
79A368-C3701-1



CAPPUCCINO CUP
2-piece set: 1 cappuccino cup in platinum
with 1 saucer in Blue Orchid platinum
79A368-C3710-1



TEA SET
8-piece set: 2 tea cups, 1 pot,
1 sugar bowl in platinum; 2 saucers
and 2 plates in Blue Orchid platinum
79A368-C3704-1



TEA CUP SET
4-piece set: 2 tea cups in platinum
with 2 saucers in Blue Orchid platinum
79A368-C3713-1



COFFEE SET
8-piece set: 2 coffee cups, 1 creamer,
1 sugar bowl in white; 2 saucers
and 2 plates in Blue Orchid platinum
79A268-C3703-1



COFFEE CUP SET
4-piece set: 2 coffee cups in white,
2 saucers in Blue Orchid platinum
79A268-C3712-1



CAPPUCCINO CUP
2-piece set: 1 cappuccino cup in white
with 1 saucer in Blue Orchid platinum
79A268-C3710-1



TEA SET
8-piece set: 2 tea cups, 1 sugar bowl,
1 pot in white; 2 saucers and 2 plates in
Blue Orchid platinum
79A268-C3704-1



TEA CUP SET
4-piece set: 2 tea cups in white,
2 saucers in Blue Orchid platinum
79A268-C3713-1





MEISSEN® COSMOPOLITAN BLUE ORCHID PLATINUM

PLATES AND SAUCERS

			
PLATE Ø 20 cm, 7 7/8" · 79A268-37071-1	STARTER PLATE Ø 22.5 cm, 8 7/8" · 79A268-37473-1	DINNER PLATE Ø 24 cm, 9 1/2" · 79A268-37475-1	DINNER PLATE Ø 30 cm, 11 3/4" · 79A268-37479-1
			
ESPRESSO SAUCER Ø 12.5 cm, 4 7/8" · 79A268-37559-1	COFFEE SAUCER Ø 16.5 cm, 6 1/2" · 79A268-37562-1	CAPPUCCINO SAUCER Ø 18 cm, 7 1/8" · 79A268-37564-1	TEA SAUCER Ø 16.5 cm, 6 1/2" · 79A268-37613-1

PLATTERS

			
PLATTER L 17 cm, 6 5/8" · 99A230-37275-1	PLATTER L 21 cm, 8 1/4" · 99A230-37276-1	PLATTER L 25 cm, 9 7/8" · 99A230-37277-1	TRAY WITH LEATHER BOTTOM L 25 cm, 9 7/8" · 99A230-37M01-1

VASES

			
VASE H 13 cm, 5 1/8" · 99A230-50192-1	VASE H 15.5 cm, 6 1/8" · 99A230-50193-1	VASE H 11 cm, 4 3/8" · 99A230-50530-1	VASE H 18 cm, 7 1/8" · 99A230-50531-1



MEISSEN® COSMOPOLITAN BLUE ORCHID
MESH WHITE AND GOLD



DINNER PLATE IN BLUE
ORCHID MESH WHITE
Ø 24 cm, 9 1/2" · 79A465-37475-1

SETS MEISSEN® COSMOPOLITAN
BLUE ORCHID MESH WHITE



COFFEE SET
9-piece set: 2 coffee cups, 1 creamer,
1 pot, 1 sugar bowl in gold; 2 saucers
and 2 plates in Blue Orchid Mesh White
79A466-C3703-1



COFFEE CUP SET
4-piece set: 2 coffee cups in gold,
2 saucers in Blue Orchid Mesh White
79A466-C3712-1



ESPRESSO CUP SET
4-piece set: 2 espresso cups in gold,
2 saucers in Blue Orchid Mesh White
79A466-C3701-1



COFFEE SET
9-piece set: 2 coffee cups, 1 creamer,
1 pot, 1 sugar bowl in white; 2 saucers
and 2 plates in Blue Orchid Mesh White
79A465-C3703-1



COFFEE CUP SET
4-piece set: 2 coffee cups in white,
2 saucers in Blue Orchid Mesh White
79A465-C3712-1



ESPRESSO CUP SET
4-piece set: 2 espresso cups in white,
2 saucers in Blue Orchid Mesh White
79A465-C3701-1



CAPPUCCINO CUP
2-piece set: 1 cappuccino cup
in gold with 1 saucer in
Blue Orchid Mesh White
79A466-C3710-1



TEA SET
9-piece set: 2 tea cups, 1 creamer,
1 pot, 1 sugar bowl in gold; 2 saucers
and 2 plates in Blue Orchid Mesh White
79A466-C3704-1



TEA CUP SET
4-piece set: 2 tea cups in gold,
2 saucers in Blue Orchid Mesh White
79A466-C3713-1



CAPPUCCINO CUP
2-piece set: 1 cappuccino cup in white,
1 saucer in Blue Orchid Mesh White
79A465-C3710-1



TEA SET
9-piece set: 2 tea cups, 1 creamer,
1 pot, 1 sugar bowl in white; 2 saucers
and 2 plates in Blue Orchid Mesh White
79A465-C3704-1



TEA CUP SET
4-piece set: 2 tea cups in white,
2 saucers in Blue Orchid Mesh White
79A465-C3713-1

MEISSEN® COSMOPOLITAN BLUE ORCHID MESH WHITE

PLATES AND SAUCERS



PLATE
Ø 20 cm, 7 7/8" · 79A465-37071-1



STARTER PLATE
Ø 22.5 cm, 8 7/8" · 79A465-37473-1



DINNER PLATE
Ø 24 cm, 9 1/2" · 79A465-37475-1



DINNER PLATE
Ø 30 cm, 11 3/4" · 79A465-37479-1



ESPRESSO SAUCER
Ø 12.5 cm, 4 7/8" · 79A465-37559-1



COFFEE SAUCER
Ø 16.5 cm, 6 1/2" · 79A465-37562-1



CAPPUCCINO SAUCER
Ø 18 cm, 7 1/8" · 79A465-37564-1



TEA SAUCER
Ø 16.5 cm, 6 1/2" · 79A465-37613-1

VIDE-POCHE



VIDE-POCHE
12.3 x 10 cm, 4 7/8" x 4"
79A465-53268-1



VIDE-POCHE
16 x 13.5 cm, 6 1/4" x 5 3/8"
79A465-53269-1



VIDE-POCHE
21 x 18.5 cm, 8 1/4" x 7 1/4"
79A465-53274-1



MEISSEN® COSMOPOLITAN BLACK MING DRAGON PLATINUM

It stands for preternatural wisdom, the spirit of change, sun, light and the male power of the yang: the Chinese Ming dragon is one of the oldest and most popular décors by MEISSEN®. Although created in 1740 based on Asian templates, in combination with clear, architectural shapes of MEISSEN® COSMOPOLITAN and with a fine platinum rim, it has a uniquely contemporary look. By the way, the typical MEISSEN® depiction of the dragon with four toes was originally reserved for items used by royal princes in ancient China.



SETS MEISSEN® COSMOPOLITAN
BLACK MING DRAGON PLATINUM



COFFEE SET
8-piece set: 2 coffee cups with platinum rim;
2 saucers, 2 plates, 1 creamer and 1 sugar bowl
with Black Ming Dragon décor and platinum rim
33A090-C3703-1



ESPRESSO SET
4-piece set: 2 espresso cups with platinum rim
with 2 saucers with Black Ming Dragon décor
and platinum rim
33A090-C3701-1



TEA SET
8-piece set: 2 tea cups with platinum rim;
2 saucers, 2 plates, 1 pot and 1 sugar bowl with
Black Ming Dragon décor and platinum rim
33A090-C3704-1



SUSHI SET
5-piece set: 1 large sushi platter with
Black Ming Dragon décor and platinum rim;
1 knife rest in platinum; 1 bowl with platinum rim;
2 chopsticks
33A090-C3705-1



COLLECTION MEISSEN® COSMOPOLITAN

BLACK MING DRAGON PLATINUM

PLATES



PLATE
Ø 20 cm, 7 7/8" · 33A090-37071-1



STARTER PLATE
Ø 22.5 cm, 8 7/8" · 33A090-37473-1



DINNER PLATE
Ø 24 cm, 9 1/2" · 33A090-37475-1



DINNER PLATE
Ø 30 cm, 11 3/4" · 33A090-37479-1



SOUP PLATE
Ø 20.5 cm, 8 1/8" · 33A090-37487-1

DISHES AND PLATTERS



SMALL DISH
L 9 cm, 3 1/2" · 33A090-53578-1



SMALL DISH
L 13 cm, 5 1/8" · 33A090-53579-1



PLATTER
L 17 cm, 6 5/8" · 33A090-37275-1



PLATTER
L 21 cm · 33A090-37276-1



PLATTER
L 25 cm, 9 7/8" · 33A090-37277-1



SUSHI PLATTER
L 27 cm, 10 5/8" · 33A090-37509-1



PLATTER, OVAL
L 25 cm, 9 7/8" · 981003-37307-1



PLATTER, OVAL
L 32 cm, 12 5/8" · 981003-37308-1

BOWLS



BOWL
Ø 6 cm, 2 3/8" · 981003-37190-1



BOWL
Ø 8 cm, 3 1/8" · 981003-37191-1



BOWL
Ø 10 cm, 4" · 981003-37192-1



BOWL
Ø 12.5 cm, 4 7/8" · 981003-37438-1



BOWL
Ø 16.5 cm, 6 1/2" · 981003-37439-1



BOWL
Ø 21 cm, 8 1/4" · 981003-37440-1

ACCESSORIES



SOUP CUP, COMPLETE
V 0.30 l, 10 1/2 oz · 33A090-37081-1



COLLECTION MEISSEN® COSMOPOLITAN
BLACK MING DRAGON PLATINUM

COFFEE AND TEA



ESPRESSO CUP, COMPLETE
V 0.05 l, 1 3/4 oz · 33A090-37579-1



COFFEE CUP, COMPLETE
V 0.20 l, 7 oz · 33A090-37582-1



CAPPUCCINO CUP,
COMPLETE
V 0.20 l, 7 oz · 33A090-37584-1



TEA CUP, COMPLETE
V 0.20 l, 7 oz · 33A090-37633-1



ESPRESSO SAUCER
Ø 12.5 cm, 4 7/8" · 33A090-37559-1



ESPRESSO CUP
V 0.05 l, 1 3/4 oz · 981003-37569-1



COFFEE SAUCER
Ø 16.5 cm, 6 1/2" · 33A090-37562-1



COFFEE CUP
V 0.20 l, 7 oz · 981003-37572-1



CAPPUCCINO SAUCER
Ø 18 cm · 33A090-37564-1



CAPPUCCINO CUP
V 0.20 l, 7 oz · 981003-37574-1



TEA SAUCER
Ø 16.5 cm, 6 1/2" · 33A090-37613-1



TEA CUP
V 0.20 l, 7 oz · 981003-37623-1



CREAMER
V 0.15 l, 5 1/4 oz · 33A090-37762-1



CREAMER
V 0.30 l, 10 1/2 oz · 33A090-37764-1



TEAPOT
V 0.6 l, 21 1/8 oz · 33A090-37726-1



COFFEE POT
V 1.0 l, 35 1/4 oz · 33A090-37727-1



SUGAR BOWL
H 8.5 cm, 3 3/8" · 33A090-37823-1





MEISSEN® COSMOPOLITAN MIAMI STYLE RED SUNSET TURQUOISE SEA

Radiantly blue skies, turquoise-coloured sea, sun, palm trees and flamingos: Miami is colourful, modern and a centre of the international art scene. It's not for nothing that "Art Miami", one of the most important art fairs in the world, takes place here every year. The art created in Miami reflects the vibrantly colourful city. It also inspired the new décor "Miami Style" by MEISSEN® COSMOPOLITAN – with two new colours that are as radiant, rich and fresh as Miami itself. "Red Sunset" and "Turquoise Sea" perfectly reflect the charm and spirit of Florida's metropolis. Welcome to Miami!





MEISSEN® COSMOPOLITAN MIAMI STYLE



VASE IN MIAMI STYLE
TURQUOISE SEA
H 21 cm, 8 1/4" · 997021-50533-1

COLLECTION MEISSEN® COSMOPOLITAN

MIAMI STYLE / TURQUOISE SEA

DISHES AND PLATTERS



SMALL DISH
L 9 cm, 3 1/2" · 997021-53578-1



SMALL DISH
L 13 cm, 5 1/8" · 997021-53579-1



PLATTER
L 17 cm, 6 5/8" · 997021-37275-1



PLATTER
L 21 cm, 8 1/4" · 997021-37276-1



PLATTER
L 25 cm, 9 7/8" · 997021-37277-1

BOWLS



BOWL
Ø 8 cm, 3 1/8" · 997021-37191-1



BOWL
Ø 10 cm, 4" · 997021-37192-1



BOWL
Ø 12.5 cm, 4 7/8" · 997021-37438-1



BOWL
Ø 16.5 cm, 6 1/2" · 997021-37439-1

CANDLEHOLDER



CANDLEHOLDER,
MIAMI STYLE LIGHT,
TURQUOISE SEA
H 6 cm, 2 3/8" · 997221-53175-1



CANDLEHOLDER,
MIAMI STYLE LIGHT
TURQUOISE SEA
H 8.5 cm, 3 3/8" · 997221-53176-1



CANDLEHOLDER,
MIAMI STYLE LIGHT
TURQUOISE SEA
H 11 cm, 4 3/8" · 997221-53177-1





COLLECTION MEISSEN® COSMOPOLITAN

MIAMI STYLE / RED SUNSET

DISHES AND PLATTERS



SMALL DISH
L 9 cm, 3 1/2" · 998021-53578-1



SMALL DISH
L 13 cm, 5 1/8" · 998021-53579-1



PLATTER
L 17 cm, 6 5/8" · 998021-37275-1



PLATTER
L 21 cm, 8 1/4" · 998021-37276-1



PLATTER
L 25 cm, 9 7/8" · 998021-37277-1

BOWLS



BOWL
Ø 8 cm, 3 1/8" · 998021-37191-1



BOWL
Ø 10 cm, 4" · 998021-37192-1



BOWL
Ø 12.5 cm, 4 7/8" · 998021-37438-1



BOWL
Ø 16.5 cm, 6 1/2" · 998021-37439-1

CANDLEHOLDER



CANDLEHOLDER,
MIAMI STYLE LIGHT,
RED SUNSET
H 6 cm, 2 3/8" · 998221-53175-1



CANDLEHOLDER,
MIAMI STYLE LIGHT,
RED SUNSET
H 8.5 cm, 3 3/8" · 998221-53176-1



CANDLEHOLDER,
MIAMI STYLE LIGHT,
RED SUNSET
H 11 cm, 4 3/8" · 998221-53177-1

MEISSEN® COSMOPOLITAN ACCESSORIES

MEISSEN® COSMOPOLITAN doesn't only adorn every table, it also includes corresponding accessories such as vases, candleholders, picture frames, vide poche and table lamps that let you stylishly furnish the entire room in a matching décor. You can also bring joy to others: gorgeous pieces made from the finest Meissen Porcelain® are always a brilliant gift idea!





ACCESSORIES VASES

MIAMI STYLE TURQUOISE SEA



VASE, MIAMI STYLE
TURQUOISE SEA
H 13 cm, 5 1/8" · 997021-50192-1



VASE, MIAMI STYLE
TURQUOISE SEA
H 15.5 cm, 6 1/8" · 997021-50193-1



VASE, MIAMI STYLE
TURQUOISE SEA
H 11 cm, 4 3/8" · 997021-50530-1



VASE, MIAMI STYLE
TURQUOISE SEA
H 18 cm, 7 1/8" · 997021-50531-1



VASE, MIAMI STYLE
TURQUOISE SEA
H 13.5 cm, 5 3/8" · 997021-50532-1



VASE, MIAMI STYLE
TURQUOISE SEA
H 21 cm, 8 1/4" · 997021-50533-1



VASE, MIAMI STYLE LIGHT,
TURQUOISE SEA
H 13 cm, 5 1/8" · 997221-50192-1



VASE, MIAMI STYLE LIGHT,
TURQUOISE SEA
H 15.5 cm, 6 1/8" · 997221-50193-1



VASE, MIAMI STYLE LIGHT,
TURQUOISE SEA
H 11 cm, 4 3/8" · 997221-50530-1



VASE, MIAMI STYLE LIGHT,
TURQUOISE SEA
H 18 cm, 7 1/8" · 997221-50531-1



VASE, MIAMI STYLE LIGHT,
TURQUOISE SEA
H 13.5 cm, 5 3/8" · 997221-50532-1



VASE, MIAMI STYLE LIGHT,
TURQUOISE SEA
H 21 cm, 8 1/4" · 997221-50533-1

ACCESSORIES VASES

MIAMI STYLE RED SUNSET

			
VASE, MIAMI STYLE RED SUNSET 13 cm, 5 1/8" · 998021-50192-1	VASE, MIAMI STYLE RED SUNSET H 15.5 cm, 6 1/8" · 998021-50193-1	VASE, MIAMI STYLE RED SUNSET 11 cm, 4 3/8" · 998021-50530-1	VASE, MIAMI STYLE RED SUNSET H 18 cm, 7 1/8" · 998021-50531-1
			
VASE, MIAMI STYLE RED SUNSET H 13.5 cm, 5 3/8" · 998021-50532-1	VASE, MIAMI STYLE RED SUNSET H 21 cm, 8 1/4" · 998021-50533-1	VASE, MIAMI STYLE LIGHT, RED SUNSET H 13 cm, 5 1/8" · 998221-50192-1	VASE, MIAMI STYLE LIGHT, RED SUNSET H 15.5 cm, 6 1/8" · 998221-50193-1
			
VASE, MIAMI STYLE LIGHT, RED SUNSET H 11 cm, 4 3/8" · 998221-50530-1	VASE, MIAMI STYLE LIGHT, RED SUNSET H 18 cm, 7 1/8" · 998221-50531-1	VASE, MIAMI STYLE LIGHT, RED SUNSET H 13.5 cm, 5 3/8" · 998221-50532-1	VASE, MIAMI STYLE LIGHT, RED SUNSET H 21 cm, 8 1/4" · 998221-50533-1



ACCESSORIES VASES

WHITE



VASE
H 13 cm, 5 1/8" · 000001-50192-1



VASE
H 15.5 cm, 6 1/8" · 000001-50193-1



VASE
H 11 cm, 4 3/8" · 000001-50530-1



VASE
H 18 cm, 7 1/8" · 000001-50531-1



VASE
H 13.5 cm, 5 3/8" · 000001-50532-1



VASE
H 21 cm, 8 1/4" · 000001-50533-1

GOLD



VASE
H 13 cm, 5 1/8" · 99A114-50192-1



VASE
H 15.5 cm, 6 1/8" · 99A114-50193-1



VASE
H 11 cm, 4 3/8" · 99A114-50530-1



VASE
H 18 cm, 7 1/8" · 99A114-50531-1



VASE
H 13.5 cm, 5 3/8" · 99A114-50532-1



VASE
H 21 cm, 8 1/4" · 99A114-50533-1



VASE, GOLD SWORDS
H 25.5 cm, 10" · 77A042-50262-1



VASE, MESH GOLD
H 25.5 cm, 10" · 79A165-50262-1

MING DRAGON BLACK



VASE
H 25.5 cm, 10" · 33A173-50262-1

ACCESSORIES VASES

PLATINUM



VASE
H 13 cm, 5 1/8" · 99A214-50192-1



VASE
H 15,5 cm, 6 1/8" · 99A214-50193-1



VASE
H 11 cm, 4 3/8" · 99A214-50530-1



VASE
H 18 cm, 7 1/8" · 99A214-50531-1



VASE
H 13,5 cm, 5 3/8" · 99A214-50532-1



VASE
H 21 cm, 8 1/4" · 99A214-50533-1



VASE, MESH PLATINUM
H 25,5 cm, 10" · 79A129-50262-1

BLUE ORCHID PLATINUM



VASE
H 13 cm, 5 1/8" · 99A230-50192-1



VASE
H 15,5 cm, 6 1/8" · 99A230-50193-1



VASE
H 11 cm, 4 3/8" · 99A230-50530-1



VASE
H 18 cm, 7 1/8" · 99A230-50531-1





ACCESSORIES PICTURE FRAMES



MIAMI STYLE TURQUOISE SEA
18 x 23 cm, 7 1/8" x 9" · 997021-53N74-1



MIAMI STYLE RED SUNSET
18 x 23 cm, 7 1/8" x 9" · 998021-53N74-1



MESH PLATIN
18 x 23 cm, 7 1/8" x 9" · 79A129-53N74-1



MESH GOLD
18 x 23 cm, 7 1/8" x 9" · 79A165-53N74-1



MESH WHITE
18 x 23 cm, 7 1/8" x 9" · 79A365-53N74-1



WHITE
18 x 23 cm, 7 1/8" x 9" · 000001-53N74-1



GOLD SWORDS
18 x 23 cm, 7 1/8" x 9" · 77A042-53N74-1



MING DRAGON BLACK
18 x 23 cm, 7 1/8" x 9" · 33A173-53N74-1



MING DRAGON RED
18 x 23 cm, 7 1/8" x 9" · 33A174-53N74-1

All picture frames are supplied in an exclusive gift box.



ACCESSORIES CANDLEHOLDER

WHITE



CANDLEHOLDER
H 6 cm, 2 3/8" · 000001-53175-1



CANDLEHOLDER
H 8.5 cm, 3 3/8" · 000001-53176-1



CANDLEHOLDER
H 11 cm, 4 3/8" · 000001-53177-1

GOLD



CANDLEHOLDER,
GOLD LIGHT
H 6 cm, 2 3/8" · 99A114-53175-1



CANDLEHOLDER,
GOLD LIGHT
H 8.5 cm, 3 3/8" · 99A114-53176-1



CANDLEHOLDER,
GOLD LIGHT
H 11 cm, 4 3/8" · 99A114-53177-1

PLATINUM



CANDLEHOLDER,
PLATINUM LIGHT
H 6 cm, 2 3/8" · 99A214-53175-1



CANDLEHOLDER,
PLATINUM LIGHT
H 8.5 cm, 3 3/8" · 99A214-53176-1



CANDLEHOLDER,
PLATINUM LIGHT
H 11 cm, 4 3/8" · 99A214-53177-1

MIAMI STYLE RED SUNSET



CANDLEHOLDER,
MIAMI STYLE LIGHT,
RED SUNSET
H 6 cm, 2 3/8" · 997221-53175-1



CANDLEHOLDER,
MIAMI STYLE LIGHT,
RED SUNSET
H 8.5 cm, 3 3/8" · 997221-53176-1



CANDLEHOLDER,
MIAMI STYLE LIGHT,
RED SUNSET
H 11 cm, 4 3/8" · 997221-53177-1

MIAMI STYLE TURQUOISE SEA



CANDLEHOLDER,
MIAMI STYLE LIGHT,
TURQUOISE SEA
H 6 cm, 2 3/8" · 998221-53175-1



CANDLEHOLDER,
MIAMI STYLE LIGHT,
TURQUOISE SEA
H 8.5 cm, 3 3/8" · 998221-53176-1



CANDLEHOLDER,
MIAMI STYLE LIGHT,
TURQUOISE SEA
H 11 cm, 4 3/8" · 998221-53177-1

ACCESSORIES VIDE-POCHE



VIDE-POCHE,
RELIEF SWORDS, WHITE
12.3 x 10 cm, 4 7/8" x 4"
000001-54268-1



VIDE-POCHE,
RELIEF SWORDS, WHITE
16 x 13.5 cm, 6 1/4" x 5 3/8"
000001-54269-1



VIDE-POCHE,
RELIEF SWORDS, WHITE
21 x 18.5 cm, 8 1/4" x 7 1/4"
000001-54274-1



VIDE-POCHE,
RELIEF DRAGON, WHITE
21 x 18.5 cm, 8 1/4" x 7 1/4"
000001-54284-1



VIDE-POCHE, MESH GOLD
12.3 x 10 cm, 4 7/8" x 4"
79A165-53268-1



VIDE-POCHE, MESH GOLD
16 x 13.5 cm, 6 1/4" x 5 3/8"
79A165-53269-1



VIDE-POCHE, MESH GOLD
21 x 18.5 cm, 8 1/4" x 7 1/4"
79A165-53274-1



VIDE-POCHE,
MESH PLATINUM
12.3 x 10 cm, 4 7/8" x 4"
79A129-53268-1



VIDE-POCHE,
MESH PLATINUM
16 x 13.5 cm, 6 1/4" x 5 3/8"
79A129-53269-1



VIDE-POCHE,
MESH PLATINUM
21 x 18.5 cm, 8 1/4" x 7 1/4"
79A129-53274-1



VIDE-POCHE,
BLUE ORCHID MESH WHITE
12.3 x 10 cm, 4 7/8" x 4"
79A465-53268-1



VIDE-POCHE,
BLUE ORCHID MESH WHITE
16 x 13.5 cm, 6 1/4" x 5 3/8"
79A465-53269-1



VIDE-POCHE,
BLUE ORCHID MESH WHITE
21 x 18.5 cm, 8 1/4" x 7 1/4"
79A465-53274-1



VIDE-POCHE,
MING DRAGON, BLACK
12.3 x 10 cm, 4 7/8" x 4"
33A173-53268-1



VIDE-POCHE,
MING DRAGON, BLACK
16 x 13.5 cm, 6 1/4" x 5 3/8"
33A173-53269-1



VIDE-POCHE,
MING DRAGON, BLACK
21 x 18.5 cm, 8 1/4" x 7 1/4"
33A173-53274-1



VIDE-POCHE, MING
DRAGON, BLACK, GOLD RIM
12.3 x 10 cm, 4 7/8" x 4"
330010-53268-1



VIDE-POCHE, MING
DRAGON, BLACK, GOLD RIM
16 x 13.5 cm, 6 1/4" x 5 3/8"
330010-53269-1



VIDE-POCHE, MING
DRAGON, BLACK, GOLD RIM
21 x 18.5 cm, 8 1/4" x 7 1/4"
330010-53274-1



VIDE-POCHE,
MING DRAGON, RED
12.3 x 10 cm, 4 7/8" x 4"
33A174-53268-1



VIDE-POCHE,
MING DRAGON, RED
16 x 13.5 cm, 6 1/4" x 5 3/8"
33A174-53269-1



VIDE-POCHE,
MING DRAGON, RED
21 x 18.5 cm, 8 1/4" x 7 1/4"
33A174-53274-1



VIDE-POCHE, MING
DRAGON, RED, GOLD RIM
12.3 x 10 cm, 4 7/8" x 4"
330510-53268-1



VIDE-POCHE, MING
DRAGON, RED, GOLD RIM
16 x 13.5 cm, 8 1/4" x 7 1/4"
330510-53269-1



VIDE-POCHE, MING
DRAGON, RED, GOLD RIM
21 x 18.5 cm, 8 1/4" x 7 1/4"
330510-53274-1

ACCESSORIES ASHTRAYS



ASHTRAY, BLACK RIM
L 21 cm, 8 1/4" · 99S090-53N76-1



ASHTRAY, MESH GOLD
L 21 cm, 8 1/4" · 79A165-53N76-1



ASHTRAY, MESH PLATINUM
L 21 cm, 8 1/4" · 79A129-53N76-1



ASHTRAY, GOLD SWORDS
L 21 cm, 8 1/4" · 77A042-53N76-1



ASHTRAY,
BLUE ORCHID MESH WHITE
L 21 cm, 8 1/4" · 79A465-53N76-1



ASHTRAY,
MING DRAGON BLACK
L 21 cm, 8 1/4" · 33A173-53N76-1



ASHTRAY,
MING DRAGON RED
L 21 cm, 8 1/4" · 330510-53N76-1

ACCESSORIES TABLE LIGHTS



CUBE, RED SUNSET
93Z246-51M67-1



CUBE, SAPPHIRE BEIGE
93Z284-51M67-1



CUBE, INDIGO BLUE
93Z222-51M67-1



CUBE, RUSSIAN GREEN
93Z230-51M67-1



CUBE, ROYAL BLUE
93Z220-51M67-1



WHITE
000001-51M67-1



GOLD
99A114-51M67-1



PLATIN
99A214-51M67-1

TECHNICAL DATA
Bulb: E14/max. 40 W; voltage: 230 V/50 Hz

 DIMENSIONS
Height 74 cm, 29 1/8"

MEISSEN® COSMOPOLITAN CRYSTAL

To perfectly complement the MEISSEN® COSMOPOLITAN table service, we now offer drinking glasses and wine-glasses made of genuine crystal glass, beautifully styled to harmonise with the colours of the porcelain décor, and adorned with their own artistically crafted décor inspired by Moroccan gardens. Use these glasses to add an additional stylish accent to your table.



DRINKING GLASSES MEISSEN® COSMOPOLITAN
DESIGN MARRAKECH



EMERALD
H 10.7 cm, 4 1/4"
XKRP01-XK093-1



COLOURED DIAMOND
H 10.7 cm, 4 1/4"
XKRP02-XK093-1



AMETHYST
H 10.7 cm, 4 1/4"
XKRP03-XK093-1



AQUAMARINE
H 10.7 cm, 4 1/4"
XKRP04-XK093-1



MANDARIN
H 10.7 cm, 4 1/4"
XKRP05-XK093-1



RUBY
H 10.7 cm, 4 1/4"
XKRP06-XK093-1



CLEAR
H 10.7 cm, 4 1/4"
XKRP07-XK093-1





WINE GOBLETS MEISSEN® COSMOPOLITAN DESIGN MARRAKECH



EMERALD
H 16 cm, 6 1/4”
XKRP01-XK094-1



COLOURED DIAMOND
H 16 cm, 6 1/4”
XKRP02-XK094-1



AMETHYST
H 16 cm, 6 1/4”
XKRP03-XK094-1



AQUAMARINE
H 16 cm, 6 1/4”
XKRP04-XK094-1



MANDARIN
H 16 cm, 6 1/4”
XKRP05-XK094-1



RUBY
H 16 cm, 6 1/4”
XKRP06-XK094-1



CLEAR
H 16 cm, 6 1/4”
XKRP07-XK094-1



EMERALD
H 17.2 cm, 6 3/4”
XKRP01-XK095-1



COLOURED DIAMOND
H 17.2 cm, 6 3/4”
XKRP02-XK095-1



AMETHYST
H 17.2 cm, 6 3/4”
XKRP03-XK095-1



AQUAMARINE
H 17.2 cm, 6 3/4”
XKRP04-XK095-1



MANDARIN
H 17.2 cm, 6 3/4”
XKRP05-XK095-1



RUBY
H 17.2 cm, 6 3/4”
XKRP06-XK095-1



CLEAR
H 17.2 cm, 6 3/4”
XKRP07-XK095-1



MEISSEN® HOME INTERIOR WITH CHARACTER

It's often the little details that give a room its unique character. In the HOME and HOME Deco collections, MEISSEN® offers much more than table and dining culture on the highest level. Because these collections embody a whole world of interior design. These furnishings, fabrics, pillows, table lamps and carpets let you decorate your room entirely in and with MEISSEN®. They perfectly harmonise with one another and they boast distinctive stylistic elements. For a stylish interior with character and an authenticity that only MEISSEN®, with its 300-year-old tradition, can claim for itself.



MEISSEN HOME ROYAL PALACE

HAND-PAINTED LEATHER CUSHIONS



ROYAL PALACE LIGHT, DRAGON LEFT
50 x 30 cm, 19 5/8" x 11 3/4"
C0012-01-001



ROYAL PALACE, DRAGON LEFT
50 x 30 cm, 19 5/8" x 11 3/4"
C0014-01-001



ROYAL PALACE
50 x 30 cm, 19 5/8" x 11 3/4"
C0016-01-001

TEXTILE PILLOWS



BLACK COUTURE
50 x 50 cm, 19 5/8" x 19 5/8"
TK0088-TK005-1



MARINE BREEZE
50 x 50 cm, 19 5/8" x 19 5/8"
TK0087-TK005-1



NOBLE KISS
50 x 50 cm, 19 5/8" x 19 5/8"
TK0090-TK005-1



NOBLE KISS
60 x 40 cm, 23 5/8" x 15 3/4"
TK0090-TK006-1



BEDUIN SUMMER
60 x 40 cm, 23 5/8" x 15 3/4"
TK0089-TK006-1



ROYAL MIDNIGHT
60 x 40 cm, 23 5/8" x 15 3/4"
TK0086-TK006-1

MATERIALS


Hand-painted leather cushions: Front: calf leather, back and piping: Satin Sun by MEISSEN COUTURE® Luxury Textiles.
Textile Pillows: Royal Palace and Satin Sun by MEISSEN® Luxury Textiles. Front: 81 % CO, 19 % PES, back: 100 % CO.

THE PRODUCT WORLD OF MEISSEN®

MEISSEN® is Europe's most tradition-rich house of fine art and hand-crafted luxury. Since it was established in 1710, the Manufactory stands for the exciting combination of unique craftsmanship and exceptional aesthetics. Discover the whole world of MEISSEN®!

TABLEWARE & DECO

fine dining arrangements, gifts, accessories, vases,
lights & candlesticks, crystal, cushions & leather cushions,
paintings on leather





ART WORKS & FIGURINES

exclusive collections, annual limited editions,
serial collectibles, unique historical pieces

ARCHITECTURE & INTERIORS

chairs, paravents, silk rugs, mirrors,
wall consoles, chandeliers



JEWELLERY & WATCHES

rings, pendants, bracelets, bangles,
earrings, necklaces, engagement rings, cufflinks, chains,
watches, writing instruments

COUTURE & ACCESSORIES

cocktail and evening dresses, leather bags, leather accessories,
silk squares, silk shawls, cashmere shawls,
cravats and pocket squares



©MEISSEN® 2016. All rights reserved.

Unless otherwise stated, all documents, images and information in this catalogue are the property of the Staatliche Porzellan-Manufaktur Meissen GmbH or relevant rights of use exist on behalf of MEISSEN®.

Photo credits: Daniele Cortese (7), Dirk Weyer (2), Fotodesign Gasparini (45), Jürgen Jeibmann (8), Maik Krause/Manufaktur Meissen (545), Schoettger Photography (15).

The use of texts and/or images, including excerpts, is only permitted with the prior written consent of the Staatliche Porzellan-Manufaktur Meissen GmbH; this naturally also applies to reproductions, disseminations, changes, etc. in information and telecommunication services of all kinds. The illustrated marks and designs are protected by law; any use and/or usage, in whatever form, is expressly prohibited without the prior written consent of the Staatliche Porzellan-Manufaktur Meissen GmbH.

MEISSEN® is synonymous with the highest quality handcrafted art objects in porcelain. Every piece is unique in its shape and décor, and each is distinguished by the characteristic “handwriting” of its designer and painter; minor differences between the actual piece and its illustration in the catalogue underscore the individuality of each item's fabrication. Furthermore, the dimensions of the artefacts are subject to minor variations caused by factors inherent to ceramic technology.

MEISSEN®, MEISSEN PORCELAIN®, Böttgersteinzeug® and Crossed Swords® are registered trademarks of the Staatliche Porzellan-Manufaktur Meissen GmbH.

www.meissen.com – phone MEISSEN® Customer dialogue: +49 (0)3521/468 66 46



XX
MEISSEN
1710