

MEISSEN® ROSES



M

MEISSEN® ROSES

ROMANCE FOR THE TABLE



The white and pink-coloured roses entwine themselves gently on the décor. Their blossoms are slightly open and the stem has small thorns, so deceptively real that you feel as though you can almost smell the heavenly scent.

Classic elegance with a touch of romance is exuded by the famous rose décor from the Biedermeier era of the mid-end of the 19th century. MEISSEN® floral painting on porcelain is a genre carved out by the manufactory itself over a long period of time and is still practised today.



The painter must think ahead while composing the motif because only a rather dull brown is available to him for the main parts of the motif. By applying the colour in varying thicknesses, he can influence the subsequent appearance and the chromatic intensity of the blossom. A metamorphosis occurs in the third and final firing, when the rose acquires its radiant colour. This graceful queen of flowers blooms tastefully and elegantly throughout the year on the MEISSEN® Roses table service.

A subtle yet elegant dining service for the special events in life.







SERVICE "NEUER AUSSCHNITT" WITH RED ROSE DÉCOR

SETS MEISSEN® ROSES RED ROSE



COFFEE SET
8-piece set: 2 coffee cups, 2 saucers, 1 creamer, 1 sugar bowl, 2 dessert plates with Red Rose décor and gold rim
020110-C0002-1



COFFEE SERVING SET
6-piece set: 2 coffee cups, 2 saucers, 2 dessert plates with Red Rose décor
020110-C0003-1



COFFEE CUP SET
4-piece set: 2 coffee cups, 2 saucers with Red Rose décor
020110-C0004-1



COFFEE MUG SET
2-piece set: 2 coffee mugs with Red Rose décor
020110-C5504-1



DISH SET
2-piece set: 2 dishes (16 cm, 6 1/4"; 12 cm, 4 3/4") with Red Rose décor
020110-C5303-1



EGG CUP SET
2-piece set: 2 egg cups with Red Rose décor
020110-C0013-1



ESPRESSO CUP SET
4-piece set: 2 espresso cups, 2 saucers with Red Rose décor
020110-C0010-1



TEA SET
8-piece set: 2 tea cups, 2 saucers, 1 pot, 1 sugar bowl, 2 dessert plates with Red Rose décor
020110-C0005-1



TEA SERVING SET
6-piece set: 2 tea cups, 2 saucers, 2 dessert plates with Red Rose décor
020110-C0006-1



CANDLEHOLDER SET
2-piece set: 2 candleholders with Red Rose décor
020110-C5302-1



CANDLEHOLDER SET
2-piece set: 2 candleholders with Red Rose décor
020110-C5301-1



TEA CUP SET
4-piece set: 2 tea cups, 2 saucers with Red Rose décor
020110-C0007-1



DINNER SET
6-piece set: 2 soup plates, 2 dinner plates, 2 dessert plates with Red Rose décor
020110-C0008-1



DESSERT DISH SET
2-piece set: 2 dessert dishes with Red Rose décor
020110-C0009-1



COLLECTION MEISSEN® ROSES RED ROSE

PLATES



PLATE
Ø 18 cm, 7 1/8" · 020110-00501-1



DESSERT PLATE
Ø 20 cm, 7 7/8" · 020110-00472-1



DINNER PLATE
Ø 25 cm, 9 7/8" · 020110-00475-1



DINNER PLATE
Ø 28 cm, 11" · 020110-00479-1



SOUP PLATE
Ø 22 cm, 8 5/8" · 020110-00488-1

COFFEE AND TEA



ESPRESSO CUP, COMPLETE
V 0.10 l, 3 1/2 oz · 020110-00580-1



COFFEE CUP, COMPLETE
V 0.20 l, 7 oz · 020110-00582-1



COFFEE MUG
V 0.25 l, 8 3/4 oz · 020110-55810-1



TEA CUP, COMPLETE
V 0.20 l, 7 oz · 020110-00633-1



SUGAR BOWL WITH ROSE
H 9 cm, 3 1/2" · 020110-00822-1



TEAPOT
V 1.0 l, 35 1/4 oz · 020110-00726-1



CREAMER
V 0.15 l, 5 1/4 oz · 020110-00763-1

BOWLS AND DISHES



BOWL
Ø 21 cm, 8 1/4" · 020110-00251-1



DESSERT DISH
Ø 14.5 cm, 5 3/4" · 020110-00411-1

ACCESSORIES



CANDY DISH
L 19 cm, 7 1/2" · 020110-00264-1



EGG CUP
H 7 cm, 2 3/4" · 020110-00179-1



CANDLEHOLDER
H 14 cm, 5 1/2" · 020110-53110-1



CANDLEHOLDER
H 7 cm, 2 3/4" · 020110-53100-1



SETS MEISSEN® ROSES WHITE ROSE



COFFEE SET
8-piece set: 2 coffee cups, 2 saucers,
1 creamer, 1 sugar bowl, 2 dessert plates
with White Rose décor
029510-C0002-1



COFFEE SERVING SET
6-piece set: 2 coffee cups, 2 saucers,
2 plates with White Rose décor
029510-C0003-1



COFFEE CUP SET
4-piece set: 2 coffee cups, 2 saucers
with White Rose décor
029510-C0004-1



DISH SET
2-piece set: 2 dishes (12 cm, 4 3/4"; 16 cm,
6 1/4") with White Rose décor
029510-C5303-1



DISH SET
2-piece set: 2 dishes with
White Rose décor
029510-C0009-1



EGG CUP SET
2-piece set: 2 egg cups with White Rose décor
029510-C0013-1



COFFEE MUG SET
2-piece set: 2 coffee mugs
with White Rose décor
029501-C5504-1



ESPRESSO CUP SET
4-piece set: 2 espresso cups,
2 saucers with White Rose décor
029510-C0010-1



TEA SERVING SET
6-piece set: 2 tea cups, 2 saucers,
2 dessert plates with White Rose décor
029510-C0006-1



CANDLEHOLDER SET
2-piece set: 2 candleholders
with White Rose décor
029510-C5301-1



CANDLEHOLDER SET
2-piece set: 2 candleholders
with White Rose décor
029510-C5302-1



TEA SERVING SET
6-piece set: 2 tea cups, 2 saucers, 2 dessert
plates with White Rose décor
029510-C0006-1



TEA CUP SET
4-piece set: 2 tea cups,
2 saucers with White Rose décor
029510-C0007-1



DINNER SET
6-piece set: 2 soup plates, 2 dinner plates,
2 dessert plates with White Rose décor
029510-C0008-1

COLLECTION MEISSEN® ROSES WHITE ROSE

PLATES



PLATE
Ø 18 cm, 7 1/8" · 029510-00501-1



DESSERT PLATE
Ø 20 cm, 7 7/8" · 029510-00472-1



DINNER PLATE
Ø 25 cm, 9 7/8" · 029510-00475-1



DINNER PLATE
Ø 28 cm, 11" · 029510-00479-1



SOUP PLATE
Ø 22 cm, 8 5/8" · 029510-00488-1

BOWLS AND DISHES



DESSERT DISH
Ø 14.5 cm, 5 3/4" · 029510-00411-1



ROASTING PLATTER
L 35 cm, 13 3/4" · 029510-00308-1



BOWL
Ø 21 cm, 8 1/4" · 029510-00251-1

COFFEE AND TEA



ESPRESSO CUP, COMPLETE
V 0.10 l, 3 1/2 oz · 029510-00580-1



COFFEE CUP, COMPLETE
V 0.20 l, 7 oz · 029510-00582-1



COFFEE MUG
V 0.25 l, 8 3/4 oz · 029501-55810-1



COFFEE MUG
V 0.25 l, 8 3/4 oz · 029510-55810



TEA CUP, COMPLETE
V 0.20 l, 7 oz · 029510-00633-1



SUGAR BOWL
H 9 cm, 3 1/2" · 029510-00822-1



CREAMER
V 0.15 l, 5 1/4 oz · 029510-00763-1



TEAPOT
V 1.0 l, 35 1/4 oz · 029510-00726-1

ACCESSORIES



CANDY DISH
L 19 cm, 7 1/2" · 029510-00264-1



EGG CUP
H 7 cm, 2 3/4" · 029510-00179-1



CANDLEHOLDER
H 14 cm, 5 1/2" · 029510-53110-1



CANDLEHOLDER
H 7 cm, 2 3/4" · 029510-53100



ACCESSORIES VASES

RED ROSE



VASE, RED ROSE
H 10.5 cm, 4 1/8" · 020110-50033-1



VASE, RED ROSE
H 14 cm, 5 1/2" · 020110-50034-1



VASE, RED ROSE
H 16 cm, 6 1/4" · 020110-50158-1



VASE, RED ROSE
H 24 cm, 9 1/2" · 020110-50198-1



VASE, RED ROSE
H 25 cm, 9 7/8" · 020110-50272-1

WHITE ROSE



VASE, WHITE ROSE
H 10.5 cm, 4 1/8" · 029510-50033-1



VASE, WHITE ROSE
H 14 cm, 5 1/2" · 029510-50034-1



VASE, WHITE ROSE
H 16 cm, 6 1/4" · 029510-50158-1



VASE, WHITE ROSE
H 24 cm, 9 1/2" · 029510-50198-1



VASE, WHITE ROSE
H 25 cm, 9 7/8" · 029510-50272-1



VASE, WHITE ROSE
H 13.5 cm, 5 3/8" · 029501-50142-1



VASE, WHITE ROSE
H 25.5 cm, 10" · 029501-50262-1

ACCESSORIES CANDLEHOLDERS



CANDLEHOLDER,
RED ROSE
H 14 cm, 5 1/2" · 020110-53110-1



CANDLEHOLDER,
RED ROSE
H 7 cm, 2 3/4" · 020110-53100-1



CANDLEHOLDER,
WHITE ROSE
H 14 cm, 5 1/2" · 029510-53110-1



CANDLEHOLDER,
WHITE ROSE
H 7 cm, 2 3/4" · 029510-53100-1

CANDLEHOLDER SETS



CANDLEHOLDER SET
2-piece set: 2 candleholders
with Red Rose décor
020110-C5302-1



CANDLEHOLDER SET
2-piece set: 2 candleholders
with Red Rose décor
020110-C5301-1



CANDLEHOLDER SET
2-piece set: 2 candleholders
with White Rose décor
029510-C5302-1



CANDLEHOLDER SET
2-piece set: 2 candleholders
with White Rose décor
029510-C5301-1

WRITING SETS



WRITING SET
2-piece set: 1 tray (L: 24 cm,
9 1/2") and 1 paper knife
with White Rose décor
029510-C5305-1



ACCESSORIES SMALL DISHES



SMALL DISH, RED ROSE
Ø 8 cm, 3 1/8" · 020110-53600-1



SMALL DISH, RED ROSE
Ø 8 cm, 3 1/8" · 020110-53601-1



SMALL DISH, RED ROSE
L 10 cm, 4" · 020110-53604-1



SMALL DISH, RED ROSE
L 12 cm, 4 3/4" · 020110-53605-1



SMALL DISH, RED ROSE
L 16 cm, 6 1/4" · 020110-53606-1



SMALL DISH, RED ROSE
L 18 cm, 7 1/8" · 020110-53607-1



SMALL DISH, WHITE ROSE
Ø 8 cm, 3 1/8" · 029510-53601-1



SMALL DISH, WHITE ROSE
L 10 cm, 4" · 029510-53604-1



SMALL DISH, WHITE ROSE
L 12 cm, 4 3/4" · 029510-53605-1



SMALL DISH, WHITE ROSE
L 16 cm, 6 1/4" · 029510-53606-1



SMALL DISH, WHITE ROSE
L 18 cm, 7 1/8" · 029510-53607-1

SMALL DISH SETS



SMALL DISH SET
2-piece set: 2 small dishes
(16 cm, 6 1/4"; 12 cm, 4 3/4")
with Red Rose décor
020110-C5303-1



SMALL DISH SET
2-piece set: 2 small dishes
(12 cm, 4 3/4"; 16 cm, 6 1/4")
with White Rose décor
029510-C5303-1



NEUER AUSSCHNITT WHITE

A fine pearl, the “little black number” of service shapes: the dining service “Neuer Ausschnitt” is one of the best pieces ever created by the gifted MEISSEN® modeller Johann Joachim Kaendler, who spent 40 years as artistic director and thus shaped the reputation of the manufactory. The oldest piece in the ensemble was created in 1745. Pure and white, it is an elegant classic all round.



SETS NEUER AUSSCHNITT WHITE



COFFEE SET
8-piece set: 2 coffee cups, 2 saucers, 1 creamer,
1 sugar bowl, 2 dessert plates in white
000001-C0002-1



COFFEE SERVING SET
6-piece set: 2 coffee cups, 2 saucers,
2 dessert plates in white
000001-C0003-1



COFFEE CUP SET
4-piece set: 2 coffee cups,
2 saucers in white
000001-C0004-1



SOUP PLATE SET
2-piece set: 2 soup plates in white
000001-C0018-1



DESSERT PLATE SET
2-piece set: 2 dessert plates in white
000001-C0016-1



DESSERT DISH SET
2-piece set: 2 dessert dishes in white
000001-C0009-1



ESPRESSO CUP SET
4-piece set: 2 espresso cups,
2 saucers in white
000001-C0010-1



TEA SET
8-piece set: 2 tea cups, 2 saucers, 1 pot,
1 sugar bowl, 2 dessert plates in white
000001-C0005-1



TEA SERVING SET
6-piece set: 2 tea cups, 2 saucers,
2 dessert plates in white
000001-C0006-1



DISH SET
2-piece set: 2 dishes
(10 cm, 4"; 12 cm, 4 3/4") in white
000001-C5319-1



EGG CUP SET
2-piece set: 2 egg cups in white
000001-C0013-1



CANDLEHOLDER SET
2-piece set: 2 candleholders in white
000001-C5302-1



TEA CUP SET
4-piece set: 2 tea cups,
2 saucers in white
000001-C0007-1



DINNER SET
6-piece set: 2 soup plates, 2 dinner plates,
2 dessert plates in white
000001-C0019-1



DINNER PLATE SET
2-piece set: 2 dinner plates in white
000001-C0017-1





COLLECTION NEUER AUSSCHNITT WHITE

PLATES



PLATE
Ø 18 cm, 7 1/8" · 000001-00501-1



DESSERT PLATE
Ø 20 cm, 7 7/8" · 000001-00472-1



DINNER PLATE
Ø 28 cm, 11" · 000001-00479-1



SOUP PLATE
Ø 22 cm, 8 5/8" · 000001-00488-1

COFFEE AND TEA



ESPRESSO CUP, COMPLETE
V 0.10 l, 3 1/2 oz · 000001-00580-1



COFFEE CUP, COMPLETE
V 0.20 l, 7 oz · 000001-00582-1



TEA CUP, COMPLETE
V 0.20 l, 7 oz · 000001-00633-1



TEAPOT
V 1.0 l, 35 1/4 oz · 000001-00726-1



CREAMER
V 0.15 l, 5 1/4 oz · 000001-00763-1



SUGAR BOWL
H 9 cm, 3 1/2" · 000001-00822-1

ACCESSORIES



EGG CUP
H 7 cm, 2 3/4" · 000001-00179-1



CUTLERY STAND
L 10 cm, 4" · 000001-00238-1



CANDLEHOLDER
H 14 cm, 5 1/2" · 000001-53110-1



DESSERT DISH
Ø 14.5 cm, 5 3/4" · 000001-00411-1

ACCESSORIES VASES

VASES



NEUER AUSSCHNITT, WHITE
H 10.5 cm, 4 1/8" · 000001-50033-1



NEUER AUSSCHNITT, WHITE
H 14 cm, 5 1/2" · 000001-50034-1



NEUER AUSSCHNITT, WHITE
H 16 cm, 6 1/4" · 000001-50035-1



NEUER AUSSCHNITT, WHITE
H 16 cm, 6 1/4" · 000001-50158-1



NEUER AUSSCHNITT, WHITE
H 24 cm, 9 1/2" · 000001-50198-1

REFERENCE NOTE

Décor no. 020101 stands for décor Red Rose with white rim
Décor no. 020110 stands for décor Red Rose with gold rim
Décor no. 029501 stands for décor White Rose with white rim
Décor no. 029510 stands for décor White Rose with white rim




THE PRODUCT WORLD OF MEISSEN®

MEISSEN® is Europe's most tradition-rich house of fine art and hand-crafted luxury. Since it was established in 1710, the Manufactory stands for the exciting combination of unique craftsmanship and exceptional aesthetics. Discover the whole world of MEISSEN®!


TABLEWARE & DECO

fine dining arrangements, gifts, accessories, vases,
lights & candlesticks, crystal, cushions & leather cushions,
paintings on leather



ART WORKS & FIGURINES

exclusive collections, annual limited editions,
serial collectibles, unique historical pieces



ARCHITECTURE & INTERIORS

chairs, paravents, silk rugs, mirrors,
wall consoles, chandeliers



JEWELLERY & WATCHES

rings, pendants, bracelets, bangles,
earrings, necklaces, engagement rings, cufflinks, chains,
watches, writing instruments



COUTURE & ACCESSORIES

cocktail and evening dresses, leather bags, leather accessories,
silk squares, silk shawls, cashmere shawls,
cravats and pocket squares



©MEISSEN® 2016. All rights reserved.

Unless otherwise stated, all documents, images and information in this catalogue are the property of the Staatliche Porzellan-Manufaktur Meissen GmbH or relevant rights of use exist on behalf of MEISSEN®.

Photo credits: Dirk Weyer (2), Fotodesign Gasparini (14), Maik Krause/Manufaktur Meissen (129)

The use of texts and/or images, including excerpts, is only permitted with the prior written consent of the Staatliche Porzellan-Manufaktur Meissen GmbH; this naturally also applies to reproductions, disseminations, changes, etc. in information and telecommunication services of all kinds. The illustrated marks and designs are protected by law; any use and/or usage, in whatever form, is expressly prohibited without the prior written consent of the Staatliche Porzellan-Manufaktur Meissen GmbH.

MEISSEN® is synonymous with the highest quality handcrafted art objects in porcelain. Every piece is unique in its shape and décor, and each is distinguished by the characteristic “handwriting” of its designer and painter; minor differences between the actual piece and its illustration in the catalogue underscore the individuality of each item's fabrication. Furthermore, the dimensions of the artefacts are subject to minor variations caused by factors inherent to ceramic technology.

MEISSEN®, MEISSEN PORCELAIN®, Böttgersteinzeug® and Crossed Swords® are registered trademarks of the Staatliche Porzellan-Manufaktur Meissen GmbH.

www.meissen.com – phone MEISSEN® Customer dialogue: +49 (0)3521/468 6637



XX
MEISSEN
1710